

Summer Shed Assembly Manual

Tools Required to Assemble:




PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the shed for health and safety purposes. We are not responsible for any injuries caused whilst assembling this shed.

Thank you for purchasing your Total Shed. All of our sheds are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to natural elements.

Each shed is carefully pre-packed and delivered in ready to assemble sections.

Loglap



Provided with Tower Bolts x2, Felt Strips, 40kg Roof Felt, Screws & Finishing Accessories

PLEASE NOTE: Shed sections may come in smaller sections and in part sections to make up all 4 side panels and roofing if access and parts are too large to assemble and access to your location. This will be established upon your order and also highlighted in your delivery package.





Summer Shed Assembly



1. Pre Assembly

1a. Lay down the floor on a level and durable foundation to take the weight of the shed and also keep a level ground to build shed on. Use a spirit level to get exact results.

1b. Place any side panel to the edge of the flooring section and then place the back section to fit perfectly in to the edge of the side section. Drill the 2 sections together once in place to make secure to each other. Do not drill to the floor section just yet.

1c. Check that the 2 panels are level upright and horizontally using a spirit level. Then place the 2nd side panel (See Pic 1c)



1d. Place side panels in position and secure to the side panels, again using 50mm screws provided.





2. Side Panels & Front

2a. When you have secured all of the side panels to the back panel. Attach the front door panel to the structure as shown on diagram 2a.

2b. Secure using screws or nails provided. Ensure the structure is suitably secured at all 4 corners and the panels are attached as shown.

PLEASE NOTE: Drill driver is best used for securing panels with the screws provided.




3. Assemble Roofing

3a. Once all the panels are secured in place then attach the roof sections as shown in diagram 3a.

3b. Align the front and rear of the roof panels to sit perfectly between the end panels as shown on point 3b. The front lip of the roof should overhang the top of front as shown on 3b.

PLEASE NOTE: Drill driver is best used for securing panels with the screws provided.

● Drill Driver




3. Secure Panels to Floor

3a. When you have secured all the panels together now using the screws provided secure the panels to the shed floor to finalise the main structure.


3b. Double check that all areas are straight and there is no loose panels. It is important to make the structure as stable as possible by screwing into the sides and flooring.

PLEASE NOTE: Drill driver is best used for securing panels with the screws provided.

● = Screw and Secure



● Drill Driver



4. Apply Roof Felt

4a. Now apply the roof felt as shown. Always apply at lowest point first to ensure correct overlap so rain water cannot run under the felt and cause any damage.

3b. Tack down the roof felt to structure and cut away any excess felt that is overhanging.

PLEASE NOTE: Neatly cut and tuck felt under roof sides

40kg Green Mineral Felt




• Stanley Knife

• Hammer

Use hammer to tack in felt to place as shown in diagram along white dotted lines.

5. Complete Roof Felt



5a. Remember to apply the lower sections of felt first (both lower sides) then the top layer from along the highest point as shown in the diagram.

Cut any excess felt and tuck under roofing edges and secure using felt tacks provided.



• Hammer
Use hammer to tack in felt to place as shown in diagram along white dotted lines.

6. Apply Felt Strips

6a. Once the roof felt is correctly applied place the felt strips provided to finish of the roofing for the shed.

Use screws provided to secure the felt strips as shown in diagram 6a.


PLEASE NOTE: Felt strips may need to be cut down to size.



• Drill Driver

50mm Screws


6a



Window Flower Box

Ideal screwing height to avoid damage

Try to screw the box as low as possible away from the glass window bottom to avoid damage to the glass.



Important Notice for Installing Window Flower Boxes.

Please note when installing the Window Flower Boxes be careful when screwing the box under the windows. Use the screws under window ledge as a guide as to how low to screw the box in as you can damage the window glass if you apply the screws too high.



7. Finishing Touches



6" Black Tower Bolt
Quality 130mm Bolt Lock

7a. Now fix your 6" Black Tower Bolt Locks to secure your sheds access.

Apply as shown with fittings provided. Look at diagram 7a.

For best results please check the sheds structure for any loose sections or areas that need extra support. This is to ensure that your shed is fully secure and has no areas that will compromise the stability of your finished shed.



• Drill Driver

Total Sheds
28 Charles Street,
Willenhall, WV13 1HG
Tel: 01902 636 529
Email: info@totalsheds.co.uk



You now have your completed Summer shed.

Ready to Assemble Summer Sheds



www.totalsheds.co.uk