




10x6ft DOG KENNEL

DELIVERED FLAT PACKED
EASY TO INSTALL SECTIONS...



Pressure Treated
Tanalised Timber for
Longer Lasting Life!



SHEDS • SUMMER HOUSES • KENNELS

PRESSURE TREATED TANALISED TIMBER

ASSEMBLY MANUAL



Kennel with Run Area


Requires a minimum build area.*
Please see details below.

10x6ft Fully Built Size

The kennel is slightly larger when fully built to cater for the finishing strips and complete unit



*Actual finished dimension area 70" x 121.2"



Total Sheds • 28 Charles Street,
Willenhall, WV13 1HG
Tel: 01902 636 529
Email: info@totalsheds.co.uk

Ready to Build Dog Kennel

Contents & Check List


10x6ft Dog Kennel

1X Kennel Floor



Page 3

4X Floor Blocks



Page 4

X2 Back Panels



Page 4 & 5

1X 2ft Back Panel



Page 5

1X Left Side Panel



Page 6

1X Right Side Panel



Page 6

1X Pop Hole Panel




Page 6

1X Front Left Panel




Page 7

1X Front Middle Panel



Page 7

1X Front Right Panel



Page 8

8X Corner Strips



Page 10

2X 4ft Kennel Roof




Page 8 & 9

1X 2ft Kennel Roof



Page 9

3X Roof Felt Sheets



Page 10

8X Felt Strips



Page 11



2 Persons Required



Pressure Treated Timber

Thank you for purchasing your Dog Kennel from Total Sheds.

All of our Kennels are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to the elements.

PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the kennel for health and safety purpose. We are not responsible for any injuries caused whilst assembling this kennel.



DELIVERED FLAT PACKED EASY TO INSTALL SECTIONS...

Each Kennel is carefully prepared in sections. Making the assembly process as easy as possible for you. Please follow our simple step-by-step guide and have your dog's new home built in no time!

Tools Required to Assemble:



HAMMER



DRILL DRIVER



STANLEY KNIFE

Supplied with 4.0 x 70mm
EASY DRILL SCREWS



Total Sheds • 28 Charles Street,
Willenhall, WV13 1HG • Tel: 01902 636 529
Email: info@totalsheds.co.uk

www.totalsheds.co.uk

Total Sheds .co.uk STEP • 1

SET THE KENNEL FOUNDATION

KENNEL FLOOR BASE

Set the base for the kennel floor to build on.

Place floor down into the required position/area. (11x7sqft recommended)
TIPS & ADVICE: It is always good to position your kennel on a solid foundation.

Slabs or Concrete areas are ideal.



Total Sheds .co.uk STEP • 2

FLOOR BLOCK x1

ATTACH FLOOR BLOCK 1



Screw in to left of floor side as shown.




FIX SIDE POST TO FLOOR EDGE WITH LARGE SCREWS

Floor Block
63mm x 38mm

Please Note: 2nd Floor Block can be sawn down in to sections to support floating panels as shown later on in build.



• = Drill Points using screws provided as shown





Total Sheds .co.uk STEP 3



ATTACH BACK PANEL 1 of 2

Position Back Panel 1

Set within the floor planks, sitting off the rear edge.



DO NOT SCREW DOWN THE PANELS TO FLOOR JUST YET!
Screw only the vertical panels to create a standing frame first, allowing room for adjustments.


Total Sheds .co.uk STEP 4



LEFT SIDE PANEL

Position Left Side Panel

Now place the Left Side Panel flush against the Back Panel Post.



Set side panel left against back panel post as shown on this image.



x3
4.0 x 70mm

● = Drill Points using screws provided as shown



DRILL DRIVER




STEP • 5

ATTACH BACK PANEL 2 of 3




Attach Back Panel 2

Use the Floor Block. Screw against 1st panel side. Where need be cut down blocks in 2ft lengths.



Position the 2nd back panel in place as shown on diagram below. The back panel 2 must be the same height as the 1st back panel which is 63mm from the ground to back panel frame bottom.



BACK PANEL 2

x3
4.0 x 70mm

● = Drill Points using screws provided as shown

Using the Floor Block Posts elevate the 2nd back panel and screw in sides to secure againsts the 1st back panel side post as shown here.



DRILL DRIVER




STEP • 6

ATTACH BACK PANEL 3 of 3



Attach Back Panel 3

Use the Floor Block to raise the 3rd back panel height then screw against 2nd back panel side.



Position the 2nd back panel in place as shown on diagram below. Use Floor Blocks to elevate. The back panel 2 must be the same height as the 1st back panel which is 63mm from the ground to back panel frame bottom.



BACK PANEL 3

x3
4.0 x 70mm

● = Drill Points using screws provided as shown

Using the Floor Block Posts, elevate the 3rd back panel and screw in sides to secure againsts the 2nd back panel side post as shown here.




DRILL DRIVER

RIGHT SIDE PANEL

Attach Right Side Panel

Now attach the Right Side Panel by placing against 2nd back panel side as below.




x3
4.0 x 70mm

● = Drill Points using screws provided as shown



● RIGHT PANEL




Using the Floor Block Posts, elevate the right side panel and screw in sides to secure againsts the 3rd back panel side post as shown.

DRILL DRIVER

POP HOLE

Place Pop Hole Panel

Set within the floor planks sitting flush with front and rear panel edges and floor.




x3
4.0 x 70mm

● = Drill Points using screws provided as shown



● POP HOLE



Position the pop hole section as shown, sitting firmly against back panel 1 and resting on the kennel floor. Screw the framework from inside against the back panel block to make stable.

DRILL DRIVER





STEP • 9

ATTACH BACK FRONT PANEL A

Front Door Panel

Now set the 1st of the front panels.
Position the solid door panel like below.



x6
4.0 x 70mm

● = Drill Points using screws provided as shown

Using the Floor Block Posts, elevate the left front panel and screw in sides to secure against the left side panel and pophole panel as shown.



DRILL DRIVER





STEP • 10


PLACE ROOF SECTION 1

Front 2ft Middle Section

Now place the mesh 2ft front panel alongside the left front panel as shown.



Secure the 2ft front mesh panel alongside the front left panel as shown



x3
4.0 x 70mm

● = Drill Points using screws provided as shown

Using the Floor Block Posts, elevate middle front panel and screw in sides to secure against the left front panel side as shown.




DRILL DRIVER

Total Sheds .co.uk STEP • 11

ATTACH BACK FRONT PANEL A


Front Mesh Panel

Now place the front mesh right panel in between the front left and right side panels.



x6
4.0 x 70mm

● = Drill Points using screws provided as shown



Using the Floor Block Posts, elevate the right front panel and place between the middle front panel and right side panel as shown.




DRILL DRIVER

Total Sheds .co.uk STEP • 12


PLACE ROOF SECTION 1

1st Roof Section

Now place the 1st of the 4ft roof panels as shown in the diagram below.



Secure roof panels by screwing them down to kennel framework as shown.



x4
4.0 x 70mm

● = Drill Points using screws provided as shown



DRILL DRIVER



STEP • 13

PLACE ROOF SECTION 2

2nd Roof Section


Now place the 2nd roof (2ft) panel as shown in the diagram below.



Now secure down the roof and the base adjusting where need be to make final structure safe & solid.

x4
4.0 x 70mm

● = Drill Points using screws provided as shown



Secure roof panels by screwing them down to kennel framework as shown. Drill downwards in to the roof framewrok so the screw meets the front & back panel framwroks from the sodes to secure further.



DRILL DRIVER



STEP • 14

PLACE ROOF SECTION 2



3rd Roof Section

Now place the 3rd roof panel as shown in the diagram below.



x4
4.0 x 70mm

● = Drill Points using screws provided as shown



Secure roof panels by screwing them down to kennel framework as shown. Drill downwards in to the roof framewrok so the screw meets the front & back panel framwroks from the sodes to secure further.

Now secure down the roof and the base adjusting where need be to make final structure safe & solid.





DRILL DRIVER

SIDE STRIPS

Attach Corner Strips

Now finish off the panels edges with the corner strips provided.

x8



Now attached the corner/side strips to hide the corners and joints between the panel sections as shown.



x16
4.0x70mm


● = Drill Points using screws provided as shown

DRILL DRIVER

APPLY ROOF FELT SHEETS x3

40kg Mineral Felt Roof

You will be provided with 2 lengths of high quality roof felt. Start with lower end of roof first.



1st Sheet at rear of roof

Proceed with 1st layer at the rear lowest point of roof, then overlay the other sections in order as shown. This method is to create rain flow towards rear of kennel.

2nd & 3rd Sheets above

Trim edges with 3" over

Fold & tack edges neatly

TACKS PROVIDED

After cutting away the excess felt, neatly fold over the edges and secure each section down by tacking them to the kennel sides. **PROTECT YOUR KENNEL AGAINST THE RAIN & ELEMENTS.**

Carefully check all the panels are fitted well and the kennel is secure and stable.

You are almost done building your kennel!

STANLEY KNIFE

HAMMER




STEP • 17

FINISH OFF WITH FELT STRIPS


Finishing Touches!

To hide the tacked felt edges add the felt strips along the top edge of roof as shown.

*Sections may come longer than required. Please saw down.



Create a neat and tidy roof finish hiding the rough edges and tacks. Measure the sides for a perfect cut and finish!



● = Drill Points using screws provided as shown

You may use **Optional Diamond Cap** to cover felt strip join

CONGRATULATIONS - YOUR DONE!




10x6ft DOG KENNEL



10x6ft Fully Built Size
The kennel is slightly larger when fully built to cater for the finishing strips and complete unit

*Actual finished dimension area 70" x 121.2"

Ready to Build Dog Kennel



Total Sheds • 28 Charles Street,
Willenhall, WV13 1HG
Tel: 01902 636 529
Email: info@totalsheds.co.uk

Dog Kennel Sizes also Available in 4x4ft to 20x6ft

Visit our website for more sizes and models.

www.totalsheds.co.uk