Shed Base Assembly Manual

Pressure Treated Tanalised Timber for Longer Lasting Life!

Ready To Build

Thank you for purchasing your Base

All of our sheds are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to the elements.

Each base is carefully packed and delivered on a pallet ready to be assembled.

FEATURES NEW FLEXIBLE, **INTER-CHANGEABLE DESIGN** FOR YOUR INDIVIDUAL STYLE.

2 Persons Recommended for Assembling The Base **Tools Required:**



HAMMER



HAND SAW



STANLEY KNIFE

PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the shed for health and safety purposes. We are not responsible for any injuries caused whilst assembling this shed.









Version 1.4

STEP • 1

STEP • 2

BASE POSTS

Lay out the timber posts into position.




LAY OUT YOUR POSTS

1a. Lay the Posts out in the area that you plan to build your shed. For this build, the longer posts will be used on the sides whilst the shorter posts will make up the center. (Refer to the Checklist to ensure the correct placement of your posts).

1b. Using a pencil, mark the drill holes. There should be two screws post end. Only the longer Posts will need to be drilled to prevent the wood from splitting.

1c. Use a Drill with a 4mm drill bit (Optional).




SCREW THE POSTS TOGETHER

Use a drill driver to tighten the screws into place.



TIGHTEN & SECURE

2a. Now, begin to assemble the Base. Starting with the corners, pull the two Posts together to form a 90 degree Corner. Use the screws to secure the Posts together.



PLEASE NOTE: Ensure that the frame is true by using a measuring tape to measure corner to corner. Do this for each corner in the form of an X. Refer to the diagram above.

